




APS MAR-DSL40C-P-U Power Transformer



Note: both primary windings must be used. Contact Mercury if you have any questions.

120V Primary Wiring	100V Primary Wiring	220V Primary Wiring	230/240V Primary Wiring
AC IN1: Brown + Black AC IN2: Brn/Wht + White FLOAT: Blk/Wht	AC IN1: Brown + Black AC IN2: Blk/Wht TIE AND FLOAT: Brn/Wht + White	AC IN1: Brown AC IN2: Blk/Wht TIE & FLOAT: Brn/Wht + Black FLOAT: White	AC IN1: Brown AC IN2: White TIE & FLOAT: Brn/Wht + Black FLOAT: Blk/Wht