




**APS MAR-SL5-P Power Transformer**



*Note: both primary windings must be used. Contact Mercury if you have any questions.*

120V Primary Wiring	100V Primary Wiring	220V Primary Wiring	230/240V Primary Wiring
AC IN1: Brown + Black AC IN2: Brn/Wht + White FLOAT: Blk/Wht	AC IN1: Brown + Black AC IN2: Blk/Wht TIE & FLOAT: Brn/Wht + White	AC IN1: Brown AC IN2: Blk/Wht TIE & FLOAT: Brn/Wht + Black FLOAT: White	AC IN1: Brown AC IN2: White TIE & FLOAT: Brn/Wht + Black FLOAT: Blk/Wht