




APS BOG-ECSTASY-P Power Transformer



Note: both primary windings must be used. Contact Mercury if you have any questions.

