




APS CER-OTS100-P Power Transformer



Note: both primary windings must be used. Contact Mercury if you have any questions.

120V Primary Wiring	100V Primary Wiring	220V Primary Wiring	230/240V Primary Wiring
AC IN1: Blk/Yel + Black AC IN2: Blk/Red + Red FLOAT: White	AC IN1: Blk/Yel + Black AC IN2: White TIE & FLOAT: Blk/Red + Red	AC IN1: Blk/Yel AC IN2: White TIE & FLOAT: Blk/Red + Black FLOAT: Red	AC IN1: Blk/Yel AC IN2: Red TIE & FLOAT: Blk/Red + Black FLOAT: White