



To adjust the Mercury
Model Checker on B, install out
the P33 leads between C1 and
C4 and allow the Model Checker
both between the two capacitors.
Snap the 47K Ohm resistor C1 and
pull it in location C4 & the C4
Resistor in the 2.2 uF cap.
When you're hooking up the PE,
remove the red Center Tap lead to
the new location shown above.



NOTES:
All voltages measured in Portable Mode
AC line voltage held constant at 120VAC 60 Hz for measurements
No signal applied. Gain and Volume set at Minimum/DV
B = Bright mode voltage T = Thick Mode voltage

Mercury
MAGNETICS

NOTE (10-29-10): THIS SCHEMATIC
SHOWS THE MERCURY MAGNETICS
TRANSFORMERS & TUBE UPGRADES
AND MODIFICATIONS.

Part Number	10044740
QTY	1
Notes	10044740